Chapter 31

Chapter 31 Virtual Terminal Communications Utility (VTCOM)

VTCOM Package 31–3
Running VTCOM 31–5
Using VTCOM 31–6
Establishing a Link with a Host 31–7
Moving Between the Host and the Local Computer 31–8
VTCOM Command Summary 31–9
Capturing the Host's Screen Image 31–12
Copying ASCII Files to and from the Host 31–13
Using the Mini-Exchange 31–15

VTCOM